



Toshiba Satellite L305D-S5895 Battery Replacement

This guide will show how to remove the battery properly from the laptop.

Written By: Daniel Matheson



INTRODUCTION

This guide will show you how to change the Battery for the Toshiba Satellite L305D-S5895.



PARTS:

- [Toshiba PA3534U-1BRS Laptop Battery](#) (1)
-

Step 1 — Battery Replacement



- Make sure switch with the number 1 is moved to the right, in the unlocked position.

Step 2



- Slide and hold switch number 2 to the left, and use your finger to pry battery out using the slot to the right of the switch.

Step 3



- Remove the battery from the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 06:09:44 AM.